

Built-In Key Lock – Model 77715 Installation Instructions

To Installer: Locking nuts are packed separately in a plastic bag containing sufficient nuts for all locks in each shipping case.

Built-in key locks can be installed on lockers with a recessed hasp or lockers with a steel hasp.



Recessed Hasp



Steel Hasp

Step 1



Open locker door, loosen and remove the nuts on the back of the hasp. Then remove the lock cover plate and the screws from the hasp.

Step 2



Align the two holes on the case assembly with the two holes on the hasp.

Step 3



With one hand, hold the case assembly in place. With the other hand, insert the screws through the front of the hasp, continuing through the holes of the case assembly.

Step 4



Place locking nuts on screw bolts and tighten. Lock is now ready to operate. **WARNING:** If electric socket wrench is used, do not exert excessive pressure.

SALSBURY INDUSTRIES

18300 Central Avenue, Carson, CA 90746-4008

Phone: 1-800-562-5377

Int'l Phone: 323-846-6700

Fax: 1-800-562-5399

Int'l Fax: 323-846-6800

www.lockers.com

engineering@lockers.com