

Industrial Storage Cabinets – 7121 & 7123

Installation Instructions

Thank you for selecting Salsbury Industries' 7121 or 7123 welded industrial storage cabinets. We are confident that the quality and construction of the cabinets will prove to be a good investment.

Due to the weight of these cabinets, it is recommended that you have a forklift or other heavy-lift device available to move them into the final installation position.

CAUTION: Due to the heavy weight of the cabinets, it is mandatory that they be securely anchored to the floor and/or wall.

No assembly is needed as the welded storage cabinets are of fully welded construction. The cabinets should be placed in the installation location and anchored to the floor, wall, or to both. Installation fasteners are not provided, as individual job conditions will dictate the type of anchor fasteners that should be used. The anchor fasteners chosen should be appropriately sized for the heavy weight of the cabinets.

7121 Single Door Industrial



7123 Three Door Industrial



SALSBURY INDUSTRIES

1010 East 62nd Street, Los Angeles, CA 90001-1598
Phone: 1-800-562-5377 Int'l Phone: 323-846-6700
Fax: 1-800-562-5399 Int'l Fax: 323-846-6800
www.lockers.com engineering@lockers.com