


# Sloping Hood & Angled Side Panel Options For Designer Open Access Lockers - 30000 Series Installation Instructions

Thank you for selecting the 30051 or 30052 sloping hood and/or the 30034 or 30044 angled side panel for the 30000 Series Designer Open Access Lockers. These instructions are intended to assist you in positioning and fastening the sloping hood and angled side panel to the locker.


## Sloping Hood Installation Instructions

1. Place the sloping hood on top of the locker.
  - Ensure the **front edge** of the hood is flush with the **front of the locker body**.
  - The **side edges** should align flush with the **sides of the locker**.
2. From inside the locker compartment, **pre-drill two pilot holes** into the bottom of the sloping hood using a 1/8" drill bit.
  - Holes should be located 13 inches from the front face of the locker.
3. Insert **two (2) 1-1/4" self-tapping wood screws** (provided) through the ceiling of the locker compartment and into the sloping hood to secure it in place.



## Angled Side Panel Installation Instructions

1. Position the angled side panel so it is **flush with the front edge** of the locker body.
2. From inside the locker, **install two (2) 1-1/4" self-tapping wood screws** (provided) through the pre-drilled holes to fasten the side panel to the locker.



## SALSBURY INDUSTRIES


18300 Central Avenue, Carson, CA 90746-4008  
Phone: 1-800-562-5377 Int'l Phone: 323-846-6700  
Fax: 1-800-562-5399 Int'l Fax: 323-846-6800  
www.lockers.com engineering@lockers.com

# Sloping Hood & Angled Side Panel Options For Designer Gear Lockers - 30000 Series Installation Instructions

Thank you for selecting the 30051 or 30052 sloping hood and/or the 30034 or 30044 angled side panel for the 30000 Series Designer Gear Lockers. These instructions are intended to assist you in positioning and fastening the sloping hood and angled side panel to the locker.


## Sloping Hood Installation Instructions

1. Place the sloping hood on top of the locker.
  - Ensure the **front edge** of the hood is flush with the **front of the locker body**.
  - The **side edges** should align flush with the **sides of the locker**.
2. From inside the locker compartment, **pre-drill two pilot holes** into the bottom of the sloping hood using a 1/8" drill bit.
  - Holes should be located 13 inches from the front face of the locker.
3. Insert **two (2) 1-1/4" self-tapping wood screws** (provided) through the ceiling of the locker compartment and into the sloping hood to secure it in place.



## Angled Side Panel Installation Instructions

1. Position the angled side panel so it is **flush with the front edge** of the locker body.
2. From inside the locker, **install two (2) 1-1/4" self-tapping wood screws** (provided) through the pre-drilled holes to fasten the side panel to the locker.



## SALSBURY INDUSTRIES

18300 Central Avenue, Carson, CA 90746-4008  
Phone: 1-800-562-5377 Int'l Phone: 323-846-6700  
Fax: 1-800-562-5399 Int'l Fax: 323-846-6800  
www.lockers.com engineering@lockers.com